

SIZECHART

HARNESS SIZE INDICATOR

MEN	HARNESS BAR SIZE	USA	XXS	XS	S	M	L	XL	XXL
		EURO	36-38	40-42	44-46	48-50	50-52	54-56	56-58
		WAIST INCH	24"-28"	26"-30"	29"-33"	33"-35"	35"-38"	37"-41"	41"-45"
		WAIST CM	60-70	67-77	75-84	82-91	89-96	94-104	102-114
		STEALTH BAR	24cm	24cm	24/28cm	28cm	28/32cm	32cm	32cm
		ACE BAR	24cm	24cm	24/28cm	28cm	28/32cm	32cm	32cm

*MEASURE WAIST SIZE CIRCUMFERENCE AT BELLYBUTTON HEIGHT

WOMEN	HARNESS BAR SIZE	USA	XS	S	M	L
		EURO	34-36	36-38	38-40	40+
		WAIST INCH	24"-28"	27"-30"	29"-33"	32"-37"
		WAIST CM	60-70	68-76	74-84	82-94
		STEALTH BAR GEN. 3	24cm	24/28cm	28cm	28cm
		STEALTH BAR	24cm	24/28cm	28cm	28cm
		ACE BAR	24cm	24/28cm	28cm	28cm

*MEASURE WAIST SIZE CIRCUMFERENCE AT BELLYBUTTON HEIGHT

JUNIOR	USA	S	M	L	XL
	EURO	140	146	152	158
	WAIST INCH	21"-23"	23"-25"	25"-27"	27"-29"
	WAIST CM	53-58	58-63	63-69	69-74

IMPACTVEST SIZE INDICATOR

MEN	USA	EURO	CHEST (CM)	CHEST (INCH)
	XXXS	42	75-80	29"-31"
	XXS	44	80-85	31"-33"
	XS	46	85-89	33"-35"
	S	48	89-94	35"-37"
	M	50	94-99	37"-39"
	L	52	99-104	39"-41"
	XL	54	104-111	41"-44"
	XXL	56	111-119	44"-47"

WOMEN	USA	EURO	CHEST (CM)	CHEST (INCH)
	XS	34	77-82	30"-32"
	S	36	82-88	32"-35"
	M	38	87-93	34"-37"
	L	40	92-99	36"-39"

FLOATATION JACKET SIZE-WEIGHT SCHEDULE

MEN	SIZE (US)	WEIGHT (IN KG)
	XS	30-40
	S	40-60
	M	60-80
	L	70+
	XL	70+

WOMEN	SIZE (US)	WEIGHT (IN KG)
	XS	30-40
	S	40-60
	M	60-80
L	70+	

HELMET SIZE INDICATOR

VANDAL PRO

SIZE	CM
XS-S	53-55
M-L	56-58
XL-XXL	59-61

VANDAL

SIZE	CM
XS-S	53-55
M-L	56-58
XL-XXL	59-61

RENTAL

SIZE	CM
XXS	50-52
XS	52-54
S	54-56
M	56-58
L	58-60
XL	60-62