

GIBBOARD®

CONGRATULATIONS *TO YOUR* GIBBOARD PRODUCT
AND WELCOME *TO THE* GIBBON TRIBE!

PLEASE USE
QR CODE TO:



WATCH SETUP VIDEO




LEARN WITH THE APP




JOIN THE TRIBE

FOR THOSE WHO CAN'T WAIT


follow these simple steps to set up and take down the Gibboard:



Thread webbing loop from the outside of the board through the desired slot of the GIBBOARD. and fix it with the „Lock“ pin. make sure the webbing is the desired way round.





Fold the webbing inward (as seen) and thread the folded webbing through the slot on the opposite side. Thread the „Roll“ pin through the resulting loop.



Apply tension by placing the Gibboard upright in front of your body with the backside facing you. Thread the „Tension Stick“ through the loop and start pulling out the slack by leaning over the GIBBOARD using your bodyweight to push down on the „Tension Stick“ until you have received the desired tension. Make sure the surface is not slippery. Roll up the remaining line and wedge it between the line and „Roll“ pin.

PARTS:



GIBOARD®

This manual contains important safety information. Before using the slackline read this manual carefully and make sure you understand and agree to all warnings, cautions, instructions, and safety recommendations.

WARNING! THE GIBOARD IS A DANGEROUS PIECE OF EQUIPMENT EVEN WHEN USED PROPERLY: Parents of minors and minors should not use the GIBOARD unless they are under constant competent adult supervision. Make sure that the GIBOARD is only used in areas where supervision is possible. Minors should not tension or detension. The GIBOARD was developed solely for one person to improve his or her balancing on the product over a flat, even and soft landing area without any obstacles, people, projections, or hazards nearby. The GIBOARD must only be handled in the manner described in this manual.

USE AT YOUR OWN RISK AND ALWAYS USE COMMON SENSE.

Always wear sturdy, tightly laced athletic shoes with flat rubber soles or barefoot. Do NOT walk the GIBOARD in sandals or using shoes with lugged soles. Keep all spectators and objects at least 2 meters (6 feet) from the GIBOARD. Never use the GIBOARD at dusk or night or in wet or icy conditions. Do NOT exceed 220 pounds (100 kg) in weight on the GIBOARD at any time. The GIBOARD is not intended for tricks, including but not limited to jumping, flipping etc. risk of injury and/or death increases.

This GIBOARD is not impervious to damage. The GIBOARD must be properly maintained and inspected before every use. Otherwise this may result in the injury and/or death. Do not use other parts not recommended.

NATURAL WEAR NOT RELATED TO WARRANTY CLAIMS:

As a sports product in usage the GIBOARD is confronted with permanent dynamic stresses. Hence natural wear will occur which includes: scratches on the bottom surface, wear on the loops, print and wooden pins and board surface. Please only wash with medium warm clear water.

ADDITIONAL SAFETY REGULATIONS:

The GIBOARD is only allowed to be tensioned by hand and by one person only. The surface used when tensioning has to avoid scratches on the product and floor. It is therefore recommended to tension and derigging over a carpet. Never handle the GIBOARD with other means than recommended. Please do not leave the GIBOARD unattended when rigged or derigged. Small children could get tangled up in the webbing or stuck between the webbing and the GIBOARD. The GIBOARD is not allowed to be modified in length by using knots.


Overloading the GIBOARD WITH MORE THAN 220 POUNDS (100 kg) AND/OR MORE THAN ONE PERSON can cause overtensioning and may cause the GIBOARD to break possibly resulting in injury and/or death. Do not use any other parts or materials to install the GIBOARD or in connection with the use of the GIBOARD other than the parts and materials provided by GIBON GIBOARDS.

You may see people on TV or on the Internet performing tricks or stunts on a GIBOARD. These are professionals who accept the risks. DO NOT ATTEMPT TO PERFORM ANY TRICKS ON THIS PRODUCT UNLESS YOU ACCEPT ALL RISK OF INJURY AND/OR DEATH.

THE MANUFACTURER AND RESELLERS OF THIS GIBOARD EXPLICITLY DISCLAIM ANY AND ALL RESPONSIBILITY AND LIABILITY FOR ANY DEATH, PARALYSIS, INJURY, AND/OR DAMAGE TO ANY PERSON OR PROPERTY THAT MAY OCCUR THAT ARISES OUT OF OR IS IN ANY WAY RELATED TO THE USE OF THIS PRODUCT.


WARRANTY:

This product is warranted against any material or manufacturing defect for two (2) years from the purchase date as stated on a valid receipt. This warranty does not cover or include any damage or defect caused by reasons mentioned above (including but not limited to any use not explicitly approved in the manual). Other than as described above, The manufacturer, sellers and resellers of this product make no other representations and/or warranties, either express or implied, regarding the product, including without limitation, any warranties as to merchantability, quality, or fitness for a particular purpose. These parties shall not be held liable in any way whatsoever for special, indirect, consequential, or incidental damages, whether based on breach of contract, breach of warranty, tort (including negligence), product liability or otherwise, even if they have advised of the possibility of such damages. The GIBOARD user agrees that it is her or his full remedy against the manufacturer, sellers, and resellers for any liability, claims, or damages, shall be limited to the purchase price of the GIBOARD, and irrevocably waive all claims for any other damages that such GIBOARD user may have.



DERIGGING:

Place the GIBOARD setup sideways on the floor ideally with carpet underneath. Use a Screwdriver or similar and a hammer to punch out the „Lock“ pin.



CORQ PADS:

in case of surface protection please stick the pads on the contact area on the bottom of the board as illustrated above.